

USER MANUAL

---

**KPM302III**

**TK202III**

**TK302III**

**CUSTOM<sup>®</sup>**



CUSTOM S.p.A.  
Via Berettine 2/B  
43010 Fontevivo (PARMA) - Italy  
Tel. : +39 0521-680111  
Fax : +39 0521-610701  
http: www.custom.biz

Assistenza Tecnica Clienti:  
www.custom4u.it

© 2025 CUSTOM S.p.A. – Italy. Tutti i diritti riservati. È vietata la riproduzione totale o parziale del presente manuale in qualsiasi forma, sia essa cartacea o informatica. CUSTOM S.p.A. e le risorse impiegate nella realizzazione del manuale, non si assumono nessuna responsabilità derivante dall'utilizzo dello stesso, garantendo che le informazioni contenute nel manuale sono state accuratamente verificate. Ogni suggerimento riguardo ad eventuali errori riscontrati o a possibili miglioramenti sarà particolarmente apprezzato. I prodotti sono soggetti ad un continuo controllo e miglioramento, pertanto CUSTOM S.p.A. si riserva di modificare le informazioni contenute nel manuale senza preavviso.

I contenuti multimediali pre/installati sono coperti da Copyright CUSTOM S.p.A. Altre società e altri nomi di prodotti qui menzionati sono marchi delle rispettive società.

La citazione di prodotti di terze parti è a solo scopo informativo e non costituisce alcun impegno o raccomandazione. CUSTOM S.p.A. declina ogni responsabilità riguardo l'uso e le prestazioni di questi prodotti.

**LE IMMAGINI UTILIZZATE NEL PRESENTE MANUALE RIVESTONO PURO SCOPO ESEMPLIFICATIVO E POTREBBERO NON RIPRODURRE FEDELMENTE IL MODELLO DESCRITTO.**

**SE NON DIVERSAMENTE SPECIFICATO, LE INFORMAZIONI FORNITE NEL PRESENTE MANUALE SONO VALIDE PER TUTTI I MODELLI IN PRODUZIONE AL MOMENTO DELL'EMISSIONE DI QUESTO DOCUMENTO.**

#### AVVERTENZE GENERALI

CUSTOM S.p.A. declina ogni responsabilità per sinistri od ogni qualsivoglia inconveniente, a persone o cose, derivanti da manomissioni, modifiche strutturali o funzionali, installazione non idonea o non correttamente eseguita, ambientazione non idonea alle protezioni o climatizzazioni richieste, carenze di manutenzione o di verifiche periodiche o di riparazioni in ogni caso non correttamente eseguite.

#### INFORMAZIONI GENERALI SULLA SICUREZZA

Si richiama l'attenzione sulle seguenti azioni che possono compromettere la conformità e le caratteristiche del prodotto:

- Leggete e conservate le istruzioni seguenti;
- Seguite tutti gli avvisi e le istruzioni indicate sul dispositivo.
- Non collocate il dispositivo su una superficie instabile perché potrebbe cadere e danneggiarsi seriamente.
- Non collocate il dispositivo su superfici morbide o in ambienti che non garantiscono la necessaria ventilazione.
- Non fissare in maniera indissolubile un prodotto o i suoi accessori come gli alimentatori se non specificatamente previsto da questo manuale.
- Collocate il dispositivo in modo da evitare che i cavi ad esso collegati possano essere danneggiati.
- [Solo apparecchiature OEM] L'apparecchiatura deve essere installata all'interno di un chiosco o sistema che fornisca protezione meccanica, elettrica, antifurto.
- L'impianto di rete deve essere conforme alle norme in vigore nel Paese in cui si intende installare l'apparecchiatura.
- Assicurarsi che nel luogo in cui si vuole installare il dispositivo, vi sia una presa di corrente facilmente accessibile e di capacità non inferiore ai 10A.
- Accertarsi che il cavo di rete in dotazione all'apparecchiatura, o che si intende utilizzare, sia compatibile con la presa disponibile nell'impianto.
- Assicuratevi che l'impianto elettrico che alimenta il dispositivo sia provvisto del conduttore di terra e che sia protetto da interruttore differenziale.
- Prima di ogni operazione di manutenzione scollegare il cavo alimentazione.
- Utilizzate il tipo di alimentazione elettrica indicato sull'etichetta del dispositivo.
- L'alimentazione alla stampante deve essere fornita da un alimentatore di tipo SELV (definizione IEC60950-1 seconda edizione).
- [Solo apparecchiature DESK] L'alimentazione all'apparecchiatura deve essere fornita da un alimentatore di tipo approvato da CUSTOM S.p.A.
- Rispettare l'intervallo operativo dell'apparecchiatura e dei componenti accessori.
- Non ostruite le aperture per la ventilazione.
- Non introducete oggetti all'interno del dispositivo in quanto essi possono cortocircuitare o danneggiare parti che potrebbero comprometterne il funzionamento.
- Non intervenite personalmente sul dispositivo, eccetto che per le operazioni di ordinaria manutenzione, espressamente riportate nel manuale utente.
- L'apparecchiatura deve essere accessibile nelle sue componenti solamente a personale autorizzato ed addestrato.
- Eseguire periodicamente la manutenzione ordinaria del dispositivo al fine di evitare che accumuli di sporcizia possano compromettere il corretto e sicuro funzionamento dell'unità.
- Non toccare la linea di riscaldamento della testina a mani nude o con oggetti metallici. Non eseguire operazioni all'interno della stampante subito dopo la stampa, perché la testina ed il motore possono raggiungere temperature molto elevate.
- Utilizzare materiali di consumo consigliati o approvati da CUSTOM S.p.A.



IL MARCHIO CE APPLICATO AL PRODOTTO CERTIFICA CHE IL PRODOTTO STESSO SODDISFA I REQUISITI BASE DI SICUREZZA.

Il dispositivo soddisfa i requisiti essenziali di Compatibilità Elettromagnetica e di Sicurezza Elettrica previsti dalle direttive 2014/30/UE e 2014/35/UE in quanto progettata in conformità alle prescrizioni delle seguenti Norme:

- EN 55032 (*Electromagnetic compatibility of multimedia equipment - Emission Requirements*)
- EN 55024/EN55035 (*Electromagnetic compatibility of multimedia equipment - Immunity requirements*)
- EN IEC/EN62368-1 (*Audio/video, information and communication technology equipment*)

Il dispositivo soddisfa i requisiti essenziali della Direttiva 2014/53/UE per le apparecchiature dotate di moduli emettitori intenzionali di onde radio. La Dichiarazione di Conformità e le altre certificazioni disponibili, possono essere scaricate dal sito [www.custom4u.it](http://www.custom4u.it).



INDICAZIONI PER LO  
SMALTIMENTO DEL  
PRODOTTO

Il simbolo del bidone barrato sta ad indicare che lo smaltimento del dispositivo NON deve essere eseguito attraverso il normale ciclo di smaltimento dei rifiuti. Per informazioni maggiormente dettagliate sul riciclaggio di questo prodotto, fare riferimento alle indicazioni dell'autorità del vostro Paese per lo smaltimento di questi prodotti.

- Non smaltire queste apparecchiature come rifiuto municipale solido misto ma effettuare una raccolta separata.
- Il reimpiego o il corretto riciclaggio delle AEE è utile a preservare l'ambiente e la salute umana stessa.
- Secondo la Direttiva europea WEEE 2012/19/UE sono disponibili specifici centri di raccolta a cui consegnare i rifiuti di apparecchiature elettriche ed elettroniche, ed è altresì possibile riconsegnare l'apparecchiatura al distributore all'atto dell'acquisto di una nuova equivalente.
- La pubblica amministrazione ed i produttori di AEE sono impegnati ad agevolare i processi di reimpiego e recupero dei RAEE attraverso l'organizzazione delle attività di raccolta e attraverso l'utilizzo di opportuni accorgimenti progettuali.
- La legge punisce con opportune sanzioni chi smaltisce abusivamente i RAEE.
- Per la raccolta differenziata delle parti componenti l'imballaggio verificare le disposizioni del proprio comune.



Il formato usato per questo manuale migliora l'uso di risorse naturali riducendo la quantità di carta necessaria per stampare questa copia.



FCC STATEMENT  
(FEDERAL COMMUNICATIONS  
COMMISSIONS).

This note is valid only for device bringing FCC trademark.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

The devices may not cause harmful interference.  
The devices must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Modifications to this product not authorized by CUSTOM S.p.A. could void the FCC & Industry Canada regulations and negate your authority to operate the product.



This product meets the ENERGY STAR® guidelines for energy efficiency.

For more information about ENERGY STAR®, visit [www.energystar.gov](http://www.energystar.gov).

This note is valid only for device bringing ENERGY STAR® trademark.


---

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

---





For details about using of tool "PrinterSet",  
refer to the manual with code **78200000001800**.



# TABLE OF CONTENTS


1	INTRODUCTION .....	9
2	IDENTIFICATION OF THE MODELS .....	11
3	DESCRIPTION .....	13
3.1	Box contents .....	13
3.2	Device components: external views .....	18
3.3	Device components: connectors panel .....	25
3.4	Device components: internal view .....	27
3.5	Device labels .....	28
3.6	Key functions: power up .....	29
3.7	Key functions: standby .....	31
3.8	Status messages .....	32
3.9	Triple feeder status messages .....	33
3.10	Messages on display .....	34
4	INSTALLATION .....	37
4.1	Fixing brackets .....	37
4.2	Fixing slots .....	41
4.3	Fixing vertical stacker .....	43
4.4	Burster configuration .....	44
4.5	Cut&Drop configuration .....	47
4.6	Connections .....	51
4.7	Pinout .....	56
4.8	Driver and SDK .....	60
5	OPERATION .....	61
5.1	Adjusting paper width .....	61
5.2	Adjusting the alignment sensors .....	65
5.3	Switch the device on .....	68
5.4	Loading the paper roll .....	73
5.5	Issuing ticket .....	81
6	CONFIGURATION .....	87
6.1	Configuration by keys .....	87
6.2	Configuration by software .....	92
6.3	Device status .....	94

6.4	Communication parameters	95
6.5	Operation parameters	97
6.6	Alignment parameters	99
6.7	Aero parameters	101
6.8	RFID parameters	104
6.9	Hexadecimal dump	106
6.10	Calendar clock	107
<b>7</b>	<b>ALIGNMENT</b>	<b>111</b>
7.1	Enable alignment	112
7.2	Calibration	113
7.3	Alignment parameters	116
<b>8</b>	<b>MAINTENANCE</b>	<b>119</b>
8.1	Printer paper jam	119
8.2	Triple feeder paper jam	129
8.3	Planning of cleaning operations	130
8.4	Cleaning	131
8.5	Upgrade firmware	136
<b>9</b>	<b>SPECIFICATION</b>	<b>137</b>
9.1	Hardware specification	137
9.2	Device dimensions	141
9.3	Device dimensions with ejector device	156
9.4	Device dimensions with paper roll holder	157
9.5	Device dimensions with height reduction kit	158
9.6	Device dimensions with power supply container	159
9.7	Device dimensions with metallic ticket tray	160
9.8	Device dimensions with plastic ticket tray	161
9.9	Device dimensions with ticket tray	162
9.10	Device dimensions with metallic ticket tray	163
9.11	Device dimensions with connectors protection	164
9.12	Device dimensions with ticket tray	166
9.13	Device dimensions with power supply container	167
9.14	Device dimensions with paper roll holder	168
9.15	Device dimensions with power supply container	169
9.16	Device dimensions with front handle	170
9.17	Device dimensions with fixing plate	173
9.18	Dimensions of power supply and power cord	175
<b>10</b>	<b>ACCESSORIES</b>	<b>179</b>
10.1	Paper roll holder	186
10.2	Wirings kit with low paper sensor boards	187
<b>11</b>	<b>TECHNICAL SERVICE</b>	<b>189</b>



# 1 INTRODUCTION

This document is divided into sections and chapters. Each chapter can be reached by the index at the beginning of this document. The index can be reached by the button on each page as shown in the diagram below.







## 2 IDENTIFICATION OF THE MODELS

NOMENCLATURE	DESCRIPTION
KPM302III	KPM302III base configuration
KPM302III TF	KPM302III with triple feeder
TK202III PLAS	TK202III with plastic chassis
TK302III PLAS	TK302III with plastic chassis
TK302III PLAS TF	TK302III with plastic chassis and triple feeder
TK302III PLAS EJ-vSTK	TK302III with plastic chassis, ejector group and vertical stacker
TK202III MET	TK202III with metal chassis
TK302III MET EJ	TK302III with metal chassis and ejector group
TK302III MET TF-EJ	TK302III with metal chassis, ejector group and triple feeder





## 3 DESCRIPTION


### 3.1 Box contents

Remove the device from its carton being careful not to damage the packing material so that it may be re-used if the device is to be transported in the future.

Make sure that all the components illustrated below are present and that there are no signs of damage. If there are, contact the customer service.


#### **KPM302III**

1. Documentation  
(installation instruction sheet)
2. Power supply cable
3. Spacer for paper width < 40 mm
4. Additional fixing bracket
5. Cut&Drop configuration kit  
(for installation, see [paragraph 4.5](#))
6. Burster configuration kit  
(for installation, see [paragraph 4.4](#))
7. Ruler
8. Device



## **KPM302III TF**


1. Documentation  
(installation instruction sheet)
2. Power supply cable
3. Cut&Drop configuration kit  
(for installation, see [paragraph 4.5](#))
4. Burster configuration kit  
(for installation, see [paragraph 4.4](#))
5. Ruler
6. Device






**TK202III PLAS, TK302III PLAS, TK302III PLAS EJ-vSTK**

1. AC adapter
2. Documentation (short guide)
3. Spacer for paper width < 40 mm
4. Ruler
5. Device




## **TK302III PLAS TF**

1. AC adapter
2. Documentation (short guide)
3. Ruler
4. Device



**TK202III MET, TK302III MET EJ, TK302III MET TF-EJ**


1. AC adapter
2. Documentation (short guide)
3. Device



## 3.2 Device components: external views


### KPM302III

- |  |                |
|--|----------------|
| 1. Print head group                        | 7. Paper input |
| 2. Device chassis                          | 8. S2 key      |
| 3. External connector for low paper sensor | 9. Status LED  |
| 4. Paper out                               | 10. S1 key     |
| 5. Front cover                             | 11. FF key     |
| 6. Opening lever for upper cover           | 12. LF key     |




## **KPM302III TF**

- |                                  |                               |
|----------------------------------|-------------------------------|
| 1. Device chassis                | 9. Triple feeder              |
| 2. Print head group              | 10. Paper input feeder 1      |
| 3. Release lever for upper cover | 11. Paper input feeder 2      |
| 4. LF key                        | 12. Paper input feeder 3      |
| 5. FF key                        | 13. Triple feeder LED (green) |
| 6. S1 key                        | 14. Triple feeder LED (red)   |
| 7. S2 key                        | 15. Paper out                 |
| 8. Status LED                    | 16. Front cover               |



## **TK302III PLAS**


1. Paper out
2. FF key
3. LF key
4. Display
5. Captive knob for connector cover opening
6. Connectors cover
7. Internal printer (see previous pages)
8. Paper input






## **TK202III PLAS. TK302III PLAS TF**

1. Paper out
2. FF key
3. LF key
4. Display
5. Internal printer with triple feeder (see previous pages)
6. Connectors cover
7. Captive knob for connector cover opening




## **TK302III PLAS EJ-vSTK**

1. FF key
2. LF key
3. Display
4. Ejector group and paper out
5. Vertical stacker
6. Captive knob for connector cover opening
7. Connectors cover
8. Internal printer (see previous pages)
9. Paper input




## **TK202III MET, TK302III MET EJ**

1. LF key
2. FF key
3. Front cover with display
4. Paper out
5. Upper cover
6. Internal printer  
(see previous pages)
7. Connectors panel  
(see [paragraph 3.3](#))
8. Paper guide (left and right)
9. Paper input



## TK302III MET TF-EJ


1. LF key
2. FF key
3. Front cover with display
4. Paper out
5. Upper cover
6. Internal printer  
(see previous pages)
7. Connectors panel  
(see [paragraph 3.3](#))




### 3.3 Device components: connectors panel

1. Cover for external low paper sensor connectors (for KPM302III TF, TK302III PLAS TF)
2. USB port
3. RS232 serial port
4. ETHERNET port
5. Slot for SD card
6. Power supply port

**KPM302III, KPM302III TF**  
**TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK**



**TK202III PLAS**




NOTE: For ease of reference, for some models is represented only the internal printer group without external chassis or triple feeder.




## **TK202III MET, TK302III MET EJ, TK302III MET TF-EJ**

1. ON/OFF key
2. Power supply port
3. USB port
4. RS232 serial port
5. ETHERNET port (only for TK302III MET EJ, TK302III MET TF-EJ)
6. External connector for low paper sensor
7. Cover for external low paper sensor connectors (only for TK302III MET TF-EJ)



### 3.4 Device components: internal view


1. Sensors for detecting paper out presence
2. Sensor for detecting the opening of the front cover
3. Sensor for detecting the cutter position (only for models with autocutter)
4. Unlocking button for mobile paper guide
5. Top mobile sensor for detecting black mark on the thermal side of paper or hole between tickets
6. Sensor for printhead temperature
7. Sensor for detecting paper presence
8. Bottom mobile sensor for detecting black mark on the non-thermal side of paper or hole between tickets
9. Sensor for detecting the opening of the upper cover



NOTE: For ease of reference, for some models is represented only the standard model of the internal printer group without external chassis or triple feeder.


## 3.5 Device labels


The main data used to identify the machine are shown on the label attached to the bottom of the device. In particular, it shows the electrical data for the connection to a power source. It also shows the product code, the serial number and the hardware revision (R).





## 3.6 Key functions: power up






**NOTE:**

During power-up, do not press the S2 key because the device enter in a test modality that becomes unusable by keys; if this event occurs then turn off the device and turn on without pressing any key.

## 3.7 Key functions: standby


**KPM302III, KPM302III TF**



**NOTE:**

(\*) Only with alignment enabled

**TK202III PLAS, TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK**  
**TK202III MET, TK302III MET EJ, TK302III MET TF-EJ**





## 3.8 Status messages

The status LED indicates hardware status of device. Given in the table below are the various LED signals and the corresponding device status.

STATUS LED		DESCRIPTION
-	OFF	DEVICE OFF
GREEN	ON	DEVICE ON: NO ERROR
GREEN COMMUNICATION STATUS	x 1	RECEIVE DATA
	x 2	RECEPTION ERRORS (PARITY, FRAME ERROR, OVERRUN ERROR)
	x 3	COMMAND NOT RECOGNIZED
	x 4	COMMAND RECEPTION TIME OUT
YELLOW RECOVERABLE ERROR	x 2	PRINthead OVERHEATED
	x 3	PAPER END
	x 4	PAPER JAM
	x 5	POWER SUPPLY VOLTAGE INCORRECT
	x 6	COVER OPEN
RED UNRECOVERABLE ERROR	x 3	RAM ERROR
	x 4	EEPROM ERROR
	x 5	CUTTER ERROR <sup>(1)</sup>
	x 6	FRONT COVER ERROR

**NOTE:**



(1) Only for models with autocutter.

## 3.9 Triple feeder status messages

### KPM302III TF, TK302III PLAS TF, TK302III MET TF-EJ

The LED panel of triple feeder is comprised of two LED (one of green colour and one of red colour) for each of the three paper input feeder.

The LED indicate the triple feeder status and the paper status. Given in the table below are the various LED signals and the corresponding triple feeder status.


STATUS LED		DESCRIPTION
RED PAPER END WARNING	OFF	PAPER PRESENCE
	ON	LOW PAPER
GREEN TRIPLE FEEDER STATUS	OFF	NO PAPER OR PAPER IN PARKING SPACE <sup>(1)</sup>
	ON	PAPER LOADED
		PAPER END DURING PRINTING
		PAPER JAM

#### NOTE:

(1) The paper is in “parking space” when it is present on the entrance of feeder but it is not loaded into the printer.

## 3.10 Messages on display

The display shows the emulation in use, the firmware release, a device status message and the outcome of the last sent command (see following image).



The possible outcomes of commands are several and they may be divided into two groups:

1. Successful outcome, which contains the OK answer to the last command (for example, PTOK)
2. Not successful outcome, which reports an error code (for example, ERR8)

The possible emulations are the following:

- ATB Emulation used to print the boarding passes
- BTP Emulation used to print the bag tags
- SER Service emulation. Generally used to configure the printer, perform updates or to print from Windows drivers

### TK202III PLAS, TK302III PLAS, TK302III PLAS EJ-vSTK TK202III MET, TK302III MET EJ

The possible status messages are the following:

- ONLINE The device is ready (standby message)
- OFFLINE The device is in a "busy" condition (during commands sending, on paper jam, and so on)
- LINK DOWN The serial connection cable is unplugged
- COVEROPEN The upper cover is open
- PAPERJAM The device has detected an anomaly along the paper path
- NOPAPER No paper loaded into the device



### **TK302III PLAS TF, TK302III MET TF-EJ**

The possible status messages are the following:

- ONLINE           The device is ready (standby message)
- OFFLINE         The device is in a “busy” condition (during commands sending, on paper jam, and so on)
- LINK DOWN       The serial connection cable is unplugged
- COVEROPEN       The upper cover is open
- PAPERJAM        The device has detected an anomaly along the paper path
- NOPAPER          No paper loaded into the device
- BIN1EMPTY        No paper loaded into the paper input 1 of the triple feeder
- BIN2EMPTY        No paper loaded into the paper input 2 of the triple feeder
- BIN3EMPTY        No paper loaded into the paper input 3 of the triple feeder





# 4 INSTALLATION


## 4.1 Fixing brackets

### KPM302III


The device includes a kit for the assembly of two additional fixing brackets (see following figure).

The kit contains:

1. Two fixing brackets;
2. No.4 fixing screws.




For the assembly procedure, proceed as follows:







The following figures (dimensions in millimetres) show the device overall dimensions with the two additional brackets.

**KPM302III**






### **KPM302III (Cut&Drop configuration)**





### **KPM302III (Burster configuration)**




## 4.2 Fixing slots

### TK202III PLAS, TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK

The device is provided with two slots for the mounting of the machine on desk.

The slots are placed at the bottom of the machine (see following figure)





The height A shown in the previous figure varies according to the accessory mounted to the device (see chapter 9).

Arrange the desk with two fixing pins according to the measures shown in the previous page and the values of the height A listed in the table below.


CONFIGURATION	HEIGHT
Device	12.5 mm
Device with paper roll holder (code 974BA010000312)	16 mm
Device with plastic ticket tray (code 976BD010000001)	18 mm
Device with metallic ticket tray (code 976BB010000003)	14.5 mm

## 4.3 Fixing vertical stacker

### TK302III PLAS EJ-vSTK


The device includes a vertical stacker for ticket storage (see [paragraph 3.1](#)). For the assembly procedure, proceed as follows.

1




Unscrew and remove the two front feet of the device.

2




Place the vertical stacker in the position shown in figure.

3



Fix the vertical stacker to the device by screwing the two feet previously removed.

4



The device is ready.


## 4.4 Burster configuration

### KPM302III, KPM302III TF

The device includes a kit for the Burster configuration (see following figure).


The kit contains:

1. Upper paper out feed mouth.



For the assembly procedure, proceed as follows:


1



Open the upper cover.




2




Unscrew the fixing screws and remove the upper paper mouth for the standard configuration.

3




Unscrew the fixing screw and remove the light guide from the paper mouth for the standard configuration.  
Using the same screw, fix the same light guide to the paper mouth for the Burster configuration.

4



Unscrew the fixing pins and take off the fixed blade and the spring.

5



Fix the paper mouth group for the Burster configuration by using the screws previously removed.

**NOTE:**

For ease of reference, for model with triple feeder is represented only the printer group without triple feeder.


## 4.5 Cut&Drop configuration

### KPM302III, KPM302III TF


The device includes a kit for the Cut&Drop configuration (see the following figure).

The kit contains:


1. Label
2. Lower paper out feed mouth.



For the assembly procedure, proceed as follows:




2




Unscrew the fixing screws and remove the upper paper mouth for the standard configuration.

3




Using a clamp, remove the precut sheet metal on the upper device cover.

4




Fix the upper paper group for the standard configuration in the upper holes on the cover using the screws previously removed.

5




Unscrew the two fixing screws on the front cover and take off the lower paper mouth of the standard configuration.

6



Fix the lower paper mouth for the Cut&Drop configuration by using the screws previously removed.

7



Close the upper cover and paste the label (supplied with the Cut&Drop kit) on the front cover.

**NOTE:**


For ease of reference, for model with triple feeder is represented only the printer group without triple feeder.

## 4.6 Connections

The following figure shows the possible connections for the device. When the RS232 and USB communication cables are connected to the printer at the same time, communication takes place via the USB port.  
For ease of reference, for some models it is represented only the printer group without the triple feeder.


**ATTENTION:** In some using conditions, we recommend the installation of a ferrite core on the power supply cable.

### KPM302III, KPM302III TF






**TK202III PLAS**







**TK202III PLAS, TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK**




## TK202III MET



# **TK302III MET EJ, TK302III MET TF-EJ**



# 4.7 Pinout




**RS232 SERIAL INTERFACE**  
Female DB9 connector

J1	1	DCD	
	2	TX	During transmission, takes the values -VRS232 and + VRS232 depending on data
	3	RX	During reception, takes the values -VRS232 and +VRS232 depending on data
	4	DSR	
	5	GND	
	6	DTR	When +VRS232, device is power on
	7	CTS	
	8	RTS	When +VRS232, device is ready to receive data
	9	n.c.	


Given the presence of the RS232 standard, logic value “0” corresponds to the voltage value +VRS232 (voltage value between +3Vdc and +15Vdc) and logic value “1” corresponds to the voltage value -VRS232 (voltage value between -3Vdc and -15Vdc).

## DEVICE > PC connection

The following picture shows an example of connection between the device and a personal computer using a 9 pin RS232 serial connector:



When use a serial cable, we recommend the installation of a ferrite core on the power supply cable.




## USB INTERFACE

Female USB type B connector

J13	1	USB-VBUS (out)
	2	PD -0
	3	PD +0
	4	GND

**KPM302III, KPM302III TF**  
**TK202III PLAS, TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK**




## POWER SUPPLY

Male Molex connector vertical (no. 39-30-0060)

J26	1	+24 Vdc
	2	+24 Vdc
	3	+24 Vdc
	4	GND
	5	GND
	6	GND

The following figure shows the connector pinout of the power supply cable:



PIN	Cable color	Signal
1	Red	+24V
2	not connected	+24V
3	Red	+24V
4	Black	GND
5	not connected	GND
6	Black	GND

**ATTENTION:**  
 Respect power supply polarity.



## TK202III MET, TK302III MET EJ, TK302III MET TF-EJ




### POWER SUPPLY

Tripolar female connector


J1

- |   |           |
|---|-----------|
| 1 | GND       |
| 2 | +24 Vdc   |
| 3 | GND       |
| 4 | Frame GND |

The following figure shows the connector pinout of the power supply cable for the device:




Tripolar male connector



**ATTENTION:**  
Respect power supply polarity.

**KPM302III, KPM302III TF**  
**TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK**  
**TK302III MET EJ, TK302III MET TF-EJ**



## ETHERNET INTERFACE

Female RJ45 connector

J16	1	TPOUT +
	2	TPOUT -
	3	TPIN +
	4	GND
	5	GND
	6	TPIN -
	7	n.c
	8	n.c
	9	+3.3 V
	10	LED-LAN
	11	+3.3 V
	12	LED-LNK
	13	Shield
	14	Shield

The functionality of two LEDs are specified in following tables:

- For 10Base-T connection:

LED	FUNCTION
LED-LNK	Link (yellow color): the LED lights up when a connection is active.
LED-LAN	Rx/Tx: (green color): the LED lights up when occurs a data reception or transmission.

- For 10/100Base-TX connection:

LED	FUNCTION
LED-LNK	The LED light (yellow color) on when a connection is active and flashes when occurs a data reception or transmission.
LED-LAN	The LED light (green color) on when occurs a 100 Mbit connection and off when occurs a 10 Mbit connection.

The device automatically recognizes the type of connection (cross or pin-to-pin).

The pinout shown in table represents the input signals to component J1 before the isolation voltage transformer (through-hole pin).



## 4.8 Driver and SDK

The drivers for the following operating system are available in the website [www.custom4u.it](http://www.custom4u.it).

OPERATING SYSTEM	DESCRIPTION	INSTALLATION PROCEDURE
Windows	Driver for Windows XP	From the START menu, press Run and type-in the path where the SW was saved on your PC, then click OK. Follow the instructions that appear on the screen to install the driver.
	Driver for Windows VISTA (32/64bit)	
	Driver for Windows 7 (32/64bit)	
	Driver for Windows 8 (32/64bit)	
	Driver for Windows 8.1 (32/64bit)	
	Driver for Windows 10 (32/64bit)	
	Driver for Virtual COM (32/64 bit) with or without silent installation (see <a href="#">paragraph 6.6</a> )	
	Driver for OPOS	
Linux	Driver for Linux (32/64bit)	Follow the instruction get back on the README.TXT file. You can find it in the software package downloaded in advance.
Android	SDK for CustomAndroidAPI	Extract the zipped folder to the destination path desired. Follow the instructions present in the software package that you downloaded on how to install and use the SDK.
iOS	SDK for CustomiOSApi	Extract the zipped folder to the destination path desired. Follow the instructions present in the software package that you downloaded on how to install and use the SDK.



# 5 OPERATION

## 5.1 Adjusting paper width


**KPM302III**

**TK202III PLAS, TK302III PLAS, TK302III PLAS EJ-vSTK**


**TK202III MET, TK302III MET EJ**

Paper width may be adjusted from 54 mm to 82.5 mm by pressing the unlocking button and moving the adjustable paper guide as shown in the figure.

If you are using TK202III MET or TK302III MET EJ it is advisable to proceed with the adjustment of the external cursors first (see next page).




1



To manage paper width of 82.5 mm,  
leave the left slider in the outer position.


2




To manage paper width of 54 mm, push the left slider  
moving it to the internal position.

If you use the device with the paper roll holder cod.974BB060000010 provided as an accessory (see [chapter 10](#)), adjust the two bushing on the roll holder pin by placing them on the notches on the spindle according to the paper width and the position of the bracket frame as follows (see also the figure):


- For 82.5 mm paper width, place both the bushings on the external notches (position A) or on the internal notches (position B).
- For 54 mm paper width, place the bushings on the two adjacent notches located on the same side of the mobile paper guide of the device, according to the assembling side of the frame (right or left).




A



C



B



D

82.5 mm paper width


54 mm paper width

# **KPM302III**

## **TK202III PLAS, TK302III PLAS, TK302III PLAS EJ-vSTK**

To manage paper width from 20 mm to 40 mm, apply the spacer provided with the device on the adjustable paper guide (see following figure), then adjust the paper width.

For ease of reference, for some models it is represented only the internal printer without external chassis.




## 5.2 Adjusting the alignment sensors


The device is equipped with two mobile sensors for the detection of the alignment black mark placed both on the thermal side and on the non-thermal side of paper as shown in the following figure.

The device user will need to manually move these mobile sensors according to the position and the type of the black mark on the paper. To use these sensors, you must set the “Black mark position” parameter on the correct value (see [chapter 6](#)).

For ease of reference, the image shows the two flats represented in the same plane and, for some models, only the internal printer group is represented without external chassis or triple feeder.



To adjust the mobile sensors position according to the black mark position and the type on paper, open the device cover and move the sensors to the desired position using a small screwdriver or a pointed object.




**ATTENTION:**

To avoid damaging the sensor, use the plastic tabs as foothold for the screwdriver to push the sensor in the desired position.

If necessary, you can use the ruler provided with some device models for a more accurate positioning. Refer to the following figure for the correct use of the ruler.



For the positioning of the bottom mobile sensor, place the ruler on the lower flat to the end point against the fixed paper guide. For the positioning of the top mobile sensor, place the ruler to the end point against the support fin on the upper flat.



## 5.3 Switch the device on


For ease of reference, for some models it is represented only the printer group without triple feeder.

### KPM302III, KPM302III TF






**1**




Rotate the captive knob to unlock the connectors cover.

**2**




Remove the connectors cover.

**3**




Power supply cable (included)



Connect the power supply cable to the device.  
Use the type of electrical power supply indicated on the label.




4



Connect the 220 V power supply cable to the power supply unit and to outlet.

5




Switch the device on by pressing the ON/OFF key on the power supply cable.

6




The display turns on with the standby message.  
The device is ready.

**1**




Connect the power adapter to the device.  
Use the type of electrical power supply indicated on the label.

**2**



Connect the power cord (optional) to the power supply and to the mains outlet.

3




Switch device on pressing the ON/OFF key.  
The display turns on and shows the message in figure.

## 5.4 Loading the paper roll

To change the paper proceed as follows. At every change of paper, check inside the device to locate and remove any scraps of paper.


**KPM302III, TK202III PLAS, TK302III PLAS, TK302III PLAS EJ-vSTK**

### 1 **TK202III PLAS** **TK302III PLAS, TK302III PLAS EJ-vSTK**




Open the  
upper plastic cover.

2



Push the opening lever  
in the direction shown in the figure.


3



**ATTENTION:**  
Pay attention to the  
exposed cutter blade.

Open the upper cover  
of the device.


4



Adjust the paper width and the position of  
the black mark sensors  
(see [paragraph 5.1](#) and [paragraph 5.2](#)).




5




Close the upper cover of the device.

6



Insert the paper into the input mouth so that it unrolls correctly. Be sure that the paper is correctly positioned into paper guides.


7



Wait until the paper is automatically loaded.

8


**TK202III PLAS**  
**TK302III PLAS, TK302III PLAS EJ-vSTK**



Close the upper plastic cover.


1

**TK302III PLAS TF**




Open the upper plastic cover.

2



Push the opening lever in the direction shown in the figure.


3



**ATTENTION:**  
Pay attention to the exposed cutter blade.

Open the upper cover of the device.


4



Adjust the paper width and the position of the black mark sensors (see [paragraph 5.1](#) and [paragraph 5.2](#)).




5



Close the upper cover  
of the device.

6




**ATTENTION:**

In case of ticket with TAG RFID, is recommended to insert the ticket into the central feeder (paper input feeder 2). The use of paper inputs 1 and 3 causes a slight bending of paper and therefore the integrity of the TAG RFID is not guaranteed. Before proceeding, check with a sample ticket.

Insert the paper into on of the input feeder so that it unrolls correctly. Be sure that the paper is correctly positioned into paper guides.


7



Wait until the paper is  
automatically loaded.

8


**TK302III PLAS TF**



Close the  
upper plastic cover.




**1**




Open the upper metal cover.

**2**




Push the opening lever in the direction shown in the figure.

**3**



Open the upper cover of the device.


**4**



Adjust the paper width and the position of the black mark sensors (see [paragraph 5.1](#) and [paragraph 5.2](#)).




5




Close the upper cover of the device.

6




Insert the paper into the input mouth so that it unrolls correctly. Be sure that the paper is correctly positioned into paper guides.

7




Wait until the paper is automatically loaded.

8




Close the upper metal cover.

1




Open the upper metal cover.

2




Push the opening lever in the direction shown in the figure.

3



Open the upper cover of the device.


4



Adjust the paper width and the position of the black mark sensors (see [paragraph 5.1](#) and [paragraph 5.2](#)).




5



Close the upper cover of the device.

6




**ATTENTION:**

In case of ticket with TAG RFID, is recommended to insert the ticket into the central feeder (paper input feeder 2). The use of paper inputs 1 and 3 causes a slight bending of paper and therefore the integrity of the TAG RFID is not guaranteed. Before proceeding, check with a sample ticket.


Insert the paper into on of the input feeder so that it unrolls correctly. Be sure that the paper is correctly positioned into paper guides.

7



Wait until the paper is automatically loaded.

8



Close the upper metal cover.

**NOTE:**

For ease of reference, in some figure is represented only the internal printer without external chassis.

## 5.5 Issuing ticket


The device allows you to choose between different operating modes for the issuance of printed tickets. The operating modes shown in following images, depend on the settings of configuration parameters and commands sent to the device. For ease of reference, for some models it is represented only the internal printer group without external chassis or triple feeder.

### **Standard mode**

**(KPM302III, KPM302III TF**


**TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK**

**TK302III MET EJ, TK302III MET TF-EJ)**




## “Cut&Hold” mode (models with ejector device)

1




The device starts the ticket printing.

2



When printing ends, the device cuts the ticket printed and hold it between the ejector rollers.


3



The device ejects the ticket printed.


# **“EJECT” mode (models with ejector device)**

1



The device starts the ticket printing.

2




When printing ends, the device cuts the ticket printed and hold it between the ejector rollers.



3

Ticket withdrew



The user withdraws the ticket printed.

NOTE: The ejector device is provided as an accessory (see [chapter 10](#)).




# 6 CONFIGURATION

## 6.1 Configuration by keys

To enter the configuration mode and print a setup report with the operating parameters of the device, proceed as follows.


### KPM302III, KPM302III TF

1




While pressing the LF key, switch on the device by connecting the power supply cable.

2




The device prints the report with the settings parameters. Follow the instruction printed on the paper or shown on display to proceed with configuration procedure.

**1**




While pressing the LF key, switch on the device by pressing the ON/OFF key on the power supply cable.

**2**




The device prints the report with the settings parameters. Follow the instruction printed on the paper or shown on display to proceed with configuration procedure.

**1**



While pressing the LF key,  
switch on the device by pressing the ON/OFF.

**2**



The device prints the report with the settings parameters. Follow the instruction printed on the paper or shown on display to proceed with configuration procedure.



The following figures show the setup reports of the device. The shown values for parameters are sample values; for the list and the description of device parameters see the following paragraphs.

PRINTER NAME and  
FIRMWARE MODULES  
RELEASE

<device name>  
SCODE: <code> - rel 1.00  
FCODE: <code> - rel 1.00  
S/N: <serial number>

PRINTER  
STATUS

## PRINTER SETTINGS

PRINTER TYPE .....<device model>  
RFID module .....Not Present  
Barcode Reader .....Not Present  
PRINthead TYPE .....<head model>  
INTERFACE .....RS232  
PROGRAM MEMORY TEST.....OK  
DYNAMIC RAM TEST.....OK  
CUTTER TEST.....OK  
HEAD VOLTAGE [V] = 24.29  
HEAD TEMPERATURE [°C] = 30  
POWER ON COUNTER = 3  
PAPER PRINTED [cm] = 10  
CUT COUNTER = 5507  
DATE - TIME = <date-time>

PRINTER  
PARAMETERS

Printer Emulation ..... **SERVICE**  
RS232 Baud Rate ..... **115200 bps**  
RS232 Data Length..... **8 bits/chr**  
RS232 Parity ..... **None**  
USB Class ..... **Printer**  
USB Address Number ..... **0**  
Print Mode ..... **Normal**  
ATB Print Quality ..... **High Quality**  
Paper Threshold ..... **60%**  
Black mark position ..... **Transparent**  
Black mark threshold ..... **30%**  
Black mark distance [mm] ..... **0.0**  
Black mark Min.Width ..... **0**  
Alignment type..... **Autocentering**  
Barcode ID 4 ..... **DataMatrix**  
Vertical Scale [%] ..... **+00.0**  
Presenter Offset [mm] ..... **+00**  
Recovery Mode ..... **Auto Check**  
ATB RePrint after ERRS..... **Disabled**  
ATB ticket length..... **Auto**  
ERRS StockType Unknown..... **Enabled**  
RFID Module Baud Rate ..... **115200 bps**  
RFID Encoding ..... **AEA Standard**  
RFID Region..... **Europe**  
RFID MIN Power ..... **0%**  
RFID MAX Power ..... **100%**  
Low Paper ..... **Disabled**  
Ejecter Type..... **Disabled**  
Ejecter Speed..... **100%**  
Busy Paper End ..... **Disabled**  
AEA Prot. ACK TOut[ms] ..... **250**  
Virtual COM Link Down ..... **Port Status**

KEYS FUNCTIONS

[LF] enter Printer Setup  
[FF] enter Ethernet Setup  
[S1] enter Clock Setup  
[S2] skip Setup



## KEYS FUNCTIONS



[LF] enter Printer Setup  
[FF] enter Ethernet Setup  
[S1] enter Clock Setup  
[S2] skip Setup

## ETHERNET PARAMETERS



NETWORK PRINTER NAME = <printer name>

DHCP Client ..... : **Disabled**

IP Address ..... : **192.168. 0. 1**

Subnet Mask ..... : **255.255.255. 0**

Default Gateway..... : **192.168. 0. 5**

Primary DNS Server..... : **0. 0. 0. 0**

Secondary DNS Server..... : **0. 0. 0. 0**

TCP Printer Port ..... : **9100**


MAC Address ..... : **00:0E:E2:00:00:00**

For advanced printer setup please connect to the site  
**<http://192.168.0.1>**

## 6.2 Configuration by software


The configuration parameters can be set by the "PrinterSet" software tool available on [www.custom4u.it](http://www.custom4u.it). For a detailed description of operating parameters for the device, see the following paragraphs.  
To set the device by software, proceed as follows.

1




Connect the device to a PC directly (see [paragraph 4.6](#)),  
without using HUB devices.

2



Start "PrinterSet" software tool.


3



Click on LOAD > FROM DEVICE and select  
the device connected to the PC.




4




Click on SETUP to access the operating parameters of the device to be configured.

5



Make the desired changes to the device operating parameters.

6



Click on SAVE > TO DEVICE to make the changes made effective.

ATTENTION: During saving, it is strongly advised against disconnecting the communication cable or to remove the power supply of PC or device.



## 6.3 Device status

The device operating status is indicated in the configuration print-out in which, next to the name of the components displayed, the following information is given:

<b>PRINTER TYPE</b>	device model
<b>RFID MODULE</b>	presence of the RFID reader/writer
<b>BARCODE READER</b>	presence of the barcode reader
<b>PRINTHEAD TYPE</b>	print head model
<b>INTERFACE</b>	interface present
<b>PROGRAM MEMORY TEST</b>	OK appears if functioning and NOT OK if faulty
<b>DYNAMIC RAM TEST</b>	OK appears if functioning and NOT OK if faulty
<b>CUTTER TEST <sup>(1)</sup></b>	OK appears if functioning and NOT OK if faulty
<b>HEAD VOLTAGE</b>	voltage of the head
<b>HEAD TEMPERATURE</b>	temperature of the head
<b>POWER ON COUNTER</b>	number of power-ups made
<b>PAPER PRINTED</b>	centimetres of paper printed
<b>CUT COUNTER <sup>(1)</sup></b>	number of cuts made
<b>DATE - TIME</b>	date and time

**NOTE:**

(1) Only for models with autocutter.



## 6.4 Communication parameters

The parameters marked with the symbol <sup>Ⓓ</sup> are the default values.

Settings remain active even after the device has been turned off and they are stored in non-volatile memory.

<b>RS232 BAUD RATE</b>	Communication speed of the serial interface.					
	115200 <sup>Ⓓ</sup>	9600				
	57600	4800				
	38400	2400				
	19200	1200				
This parameter is valid only with serial interface.						
<b>RS232 DATA LENGTH</b>	Number of bit used for characters encoding.					
	7 bits/car					
	8 bits/car <sup>Ⓓ</sup>					
This parameter is valid only with serial interface.						
<b>RS232 PARITY</b>	Bit for the parity control of the serial interface.					
	None <sup>Ⓓ</sup>	=	parity bit omitted			
	Even	=	even value for parity bit			
	Odd	=	odd value for parity bit			
	This parameter is valid only with serial interface.					
<b>USB CLASS</b>	USB communication class definition.					
	Printer <sup>Ⓓ</sup>	=	setting the printer function			
	Virtual COM	=	setting the USB port as a virtual serial port			
	To use the value "Virtual COM", it is necessary to install an additional driver (see <a href="#">paragraph 4.8</a> )					
<b>USB ADDRESS NUMBER</b>	Numerical address code for the univocal identification of the USB device (in case of more than a USB device connected with the same PC).					
	0 <sup>Ⓓ</sup>	2	4	6	8	10
	1	3	5	7	9	None
	If the parameter is set on "None", the device is identified by the physical USB port to which it is connected.					
<b>NETWORK PRINTER NAME</b>	This is the number, provided by the constructor, that identifies the device:					
	KPM300HIII					
	This parameter is not modifiable during the setup procedure.					



<b>DHCP CLIENT</b>	Setting of the DHCP protocol:  Disabled <sup>D</sup> = protocol disabled Enabled = protocol enabled  This parameter can be modified only by software (see <a href="#">paragraph 6.2</a> ).								
<b>IP ADDRESS</b>	This is the IP address of device, assigned by the network administrator. This parameter can be modified only by software (see <a href="#">paragraph 6.2</a> ).								
<b>SUBNET MASK</b>	This parameter identifies the local network address. This parameter can be modified only by software (see <a href="#">paragraph 6.2</a> ).								
<b>DEFAULT GATEWAY</b>	This parameter identifies the Gateway IP address used to send applications to the external network. This parameter can be modified only by software (see <a href="#">paragraph 6.2</a> ).								
<b>PRIMARY DNS SERVER</b>	This parameter identifies the primary DNS server (Domain Name System). It can be modified only by software (see <a href="#">paragraph 6.2</a> ).								
<b>SECONDARY DNS SERVER</b>	This parameter identifies the secondary DNS server (Domain Name System). It can be modified only by software (see <a href="#">paragraph 6.2</a> ).								
<b>TCP PRINTER PORT</b>	This parameter sets the TCP port number. It can be modified only by software (see <a href="#">paragraph 6.2</a> ).								
<b>MAC ADDRESS</b>	This is the number, provided by the constructor, that identifies the device; this number is univocal. This parameter is not modifiable during the setup procedure.								
<b>RFID MODULE BAUD RATE</b>	Communication speed of the RFID module.  <table><tr><td>115200 <sup>D</sup></td><td>9600</td></tr><tr><td>57600</td><td>4800</td></tr><tr><td>38400</td><td>2400</td></tr><tr><td>19200</td><td>1200</td></tr></table> If the RFID module is not recognized in the printer status ("RFID module = Not Present"), set this parameter on the correct value.	115200 <sup>D</sup>	9600	57600	4800	38400	2400	19200	1200
115200 <sup>D</sup>	9600								
57600	4800								
38400	2400								
19200	1200								

**ATTENTION:**

Any changes to network parameters will interrupt browser connection. If the server not responding you must reconnect to the new IP address set.



## 6.5 Operation parameters

The parameters marked with the symbol <sup>D</sup> are the default values.

Settings remain active even after the device has been turned off and they are stored in non-volatile memory.

<b>PRINTER EMULATION</b>	Available emulations for the device.  SERVICE <sup>D</sup> = used only for upgrade BTP = used for management of baggages ticket ATB = used for management of boarding ticket
<b>CUTTER</b>	Setting of the autocutter at the hardware level:  Disabled = autocutter disabled Enabled <sup>D</sup> = autocutter enabled  For the device described in this document, keep this parameter set on "Enabled", as the default value.
<b>EXTERNAL KEYS</b>	<b><u>TK202III PLAS, TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK</u></b> <b><u>TK202III MET, TK302III MET EJ, TK302III MET TF-EJ</u></b>  Setting of the external keys  Disabled = external keys disabled Enabled <sup>D</sup> = external keys enabled
<b>LOW PAPER</b>	Setting of the low paper detection:  Disabled <sup>D</sup> = detection disabled Enabled = detection enabled
<b>PRINT MODE</b>	Printing mode.  Normal <sup>D</sup> = enables printing in normal writing way Reverse = enables printing rotated 180 degrees
<b>ATB PRINT QUALITY</b>	Setting of speed and printing quality.  High Quality <sup>D</sup> Normal High Speed
<b>PAPER THRESHOLD</b>	Threshold value (in percent) for the recognition of the presence of paper by the paper presence sensor.  30% 70% 40% <sup>D</sup> 80% 50% 90% 60%



---

## EJECTOR SPEED

Setting of the speed of the ejector front:

25%    75%  
50%    100% <sup>D</sup>

This parameter is valid only for models with the ejector device available as accessory (see [chapter 10](#)).

---

## EJECTOR TYPE

Management of the ejector device:

Disabled <sup>D</sup> = ejector disabled  
Presenter = after the printing end, the device cuts the ticket and holds it between the ejector rollers in a "cut & hold" mode waiting for the user withdrawal  
Ejecter = after the printing end, the device cut the ticket and eject it

The "cut & hold" mode (see [paragraph 5.5](#)) must be enabled by protocol. Otherwise, the device performs an eject even if this parameter is set on "Presenter" value.

This parameter is valid only for models with the ejector device available as accessory (see [chapter 10](#)).

---

## 6.6 Alignment parameters

The parameters marked with the symbol <sup>D</sup> are the default values.

Settings remain active even after the device has been turned off and they are stored in non-volatile me.

<b>BLACK MARK POSITION</b>	Position of the alignment black mark and choice of appropriate black mark sensor (see <a href="#">chapter 7</a> ):				
	Disabled	=	the black mark alignment is not performed		
	Top	=	the black mark position is detected by the top sensor (reflection)		
	Bottom	=	the black mark position is detected by the bottom sensor (reflection)		
	Transparent <sup>D</sup>	=	the black mark is detected by the bottom sensor and the top sensor placed in front of (transparence)		
<hr/>					
<b>BLACK MARK THRESHOLD</b>	Threshold value (in percent) for the recognition of the presence of black mark by the black mark sensor:				
	30%	70%			
	40%	80%			
	50%	90%			
	60% <sup>D</sup>				
	If parameter "Black mark position" is set on "Disabled", this parameter has no effect on device configuration and it is not printed on setup report.				
<hr/>					
<b>BLACK MARK DISTANCE</b>	"Black mark distance" is the minimum distance (in millimetres) between the upper edge of ticket and the black mark (see <a href="#">chapter 7</a> ).				
	The numeric value of the distance is made up with the following four parameters for the setting of three digits (two for the integer part of the number, one for the decimal part and of the sign):				
<hr/>					
	Sign setting:				
BLACK MARK DISTANCE SIGN	+ <sup>D</sup>	=	positive distance		
	-	=	negative distance		
<hr/>					
	Setting the digit for tens:				
BLACK MARK DISTANCE [mm x 10]	0 <sup>D</sup>	2	4	6	8
	1	3	5	7	9
<hr/>					
	Setting the digit for units:				
BLACK MARK DISTANCE [mm x 1]	0 <sup>D</sup>	2	4	6	8
	1	3	5	7	9
<hr/>					
	Setting the digit for decimals:				
BLACK MARK DISTANCE [mm x .1]	0 <sup>D</sup>	2	4	6	8
	1	3	5	7	9
<hr/>					
	The parameter is printed on setup report only if "Alignment type" parameter is set on "Edge" and the "Black mark position" parameter is set on a value other than "Disabled".				



---

**BLACK MARK  
MIN. WIDTH**

This parameter set the minimum length of the black mark in order to avoid that other graphics present on the ticket can be detected as a black mark.

0 mm <sup>D</sup>	6 mm	12 mm	18 mm
1 mm	7 mm	13 mm	19 mm
2 mm	8 mm	14 mm	20 mm
3 mm	9 mm	15 mm	
4 mm	10 mm	16 mm	
5 mm	11 mm	17 mm	

The parameter is printed on setup report only if "Alignment type" parameter is set on "Edge" and the "Black mark position" parameter is set on a value other than "Disabled".

---

**ALIGNMENT TYPE**

This parameter defines the point for the black mark alignment:

Autocentering <sup>D</sup> = the point for the black mark alignment is the center of black mark  
Edge = the point for the black mark alignment is the frontal edge of black mark  
DETLTYPE = black mark sensor is set by command

---





## 6.7 Aero parameters

The parameters marked with the symbol <sup>D</sup> are the default values.

Settings remain active even after the device has been turned off and they are stored in non-volatile me.

<b>DOT FAIL TEST</b>	<p>Setting of the automatic check of damaged dots:</p> <p>Disabled <sup>D</sup> = automatic check disabled Enabled = the printer performs automatic check of damaged dots and reports them as per AEA specifications</p>
<b>USB LINK DOWN</b>	<p>Select method to display LINK DOWN /ONLINE when printer is connected with USB:</p> <p>Port Status = use virtual DTR <sup>D</sup> Plug = use usb plug</p>
<b>AEA PROTOCOL STX</b>	<p>Value of the start byte of protocol (up to three bytes, expressed in hexadecimal). If '00' value is set, this parameter is disabled.</p> <p>This parameter is not printed on setup report. You can set this parameter only by software (see <a href="#">paragraph 6.2</a>). Moreover, it may not be available for some models.</p>
<b>AEA PROTOCOL ETX</b>	<p>Value of the end byte of protocol (up to three bytes, expressed in hexadecimal). This parameter can not be disabled, unlike the "AEA PROTOCOL STX".</p> <p>This parameter is not printed on setup report. You can set this parameter only by software (see <a href="#">paragraph 6.2</a>). Moreover, it may not be available for some models.</p>
<b>AEA PROTOCOL CHECKSUM</b>	<p>Set type of checksum for AEA protocol:</p> <p>NONE LRC DRC LRC+DRC CRC16</p> <p>This parameter is not printed on setup report. You can set this parameter only by software (see <a href="#">paragraph 6.2</a>). Moreover, it may not be available for firmware versions.</p>
<b>BUFFERED PRINT</b>	<p>When enabled disable support for ERR7 management (see IATA ITPS specifications for ERR7 description).</p>
<b>LEGACY COMMANDS</b>	<p>Enables support for legacy commands.</p>
<b>AEA PROT. ACK TOUT [MS]</b>	<p>Set the timeout (expressed in milliseconds) to wait for Ack from host:</p> <p>from 0 ms to 9999 ms</p> <p>This parameter is ignored if "AEA protocol checsum" is set to "None" value.</p>



<b>BUSY PAPER END</b>	<p>Activation mode for busy signal on serial interface:</p> <p>Disabled <sup>D</sup> = busy signal is not activated in case of paper end Enabled = busy signal is activated in case of paper end</p>
<b>BARCODE ID 4</b>	<p>Setting of the barcode format associated with ID 4 (see AEA specifications):</p> <p>Code128 = sets the Code128 format DataMatrix <sup>D</sup> = sets the DataMatrix format</p> <p>If parameter "Printer emulation" is set on "Service", this parameter has no effect on device configuration and it is not printed on setup report.</p>
<b>VERTICAL SCALE [%]</b>	<p>Adjust of the printing positions by adding the percentage value to the coordinates of elements (in the direction of the length of the ticket).</p> <p>If parameter "Printer emulation" is set on "Service", this parameter has no effect on device configuration and it is not printed on setup report.</p>
<b>PRESENTER OFFSET [mm]</b>	<p>Setting of the presentation distance of ticket in case of presentation mode enabled (paper cut disabled).</p> <p>If parameter "Printer emulation" is set on "Service", this parameter has no effect on device configuration and it is not printed on setup report.</p>
<b>ATB TICKET LENGTH</b>	<p>This parameter defines the detection mode of the ticket length:</p> <p>Auto <sup>D</sup> = at the paper autoloading, the device automatically calculates the ticket length by detecting two consecutive black marks and then recover the first ticket used for detection Auto No Recovery = at the paper autoloading, the device automatically calculates the ticket length by detecting two consecutive black marks. The ticket used for detection is not recovered. 8" Fixed = the ticket length is set to 8" 7" 3/8 Fixed = the ticket length is set to 7" 3/8</p> <p>If parameter "Printer emulation" is set on "Service" or "BTP", this parameter has no effect on device configuration and it is not printed on setup report.</p>
<b>ATB REPRINT AFTER ERRS</b>	<p>This parameter enables/disables the automatic reprint of a ticket stopped due to a paper jam or a paper end</p> <p>Disabled <sup>D</sup> = reprint disabled Enabled = reprint enabled</p> <p>If parameter "Printer emulation" is set on "Service" or "BTP", this parameter has no effect on device configuration and it is not printed on setup report.</p>
<b>ERRS STOCKTYPE UNKNOWN</b>	<p>This parameter enables/disables the management of the ERRS:</p> <p>Disabled = ERRS management disabled Enabled <sup>D</sup> = ERRS management enabled</p>



---

**RECOVERY MODE**

Setting of recovery mode for paper portion on output mouth after a ticket presentation and withdrawal:

- Auto Check = device automatically detect paper presence on output sensor and then recovers a fixed portion of paper
- Fixed <sup>D</sup> = device recovers a fixed portion of paper (set by command)

The parameter is printed on setup report only if the "Printer emulation" parameter is set on value "ATB" or "BTP" and only with cut disabled by commands (refer to the command manual of the device).

---

**CR LF ACCEPT**

Selects if accept pectables with elements separated with additional CR LF:

Disabled <sup>D</sup>  
CR LF  
LF

---



## 6.8 RFID parameters

### models with RFID reader/writer

The parameters marked with the symbol <sup>Ⓓ</sup> are the default values.

Settings remain active even after the device has been turned off and they are stored in non-volatile me.

RFID ENCODING	Setting of the coding system used for the writing of the RFID chip:				
	AEA2007 RP1740C <sup>Ⓓ</sup>				
	The parameter is printed on setup report only if the "Printer emulation" parameter is set on value "ATB" or "BTP".				
RFID REGION	Set working frequency for RFID module:				
	Europe	856-867 MHz			
	FCC	902-927 MHz			
	Japan	952-953 MHz			
	Japan T106	916-920 MHz			
	Japan T107	916-923 MHz			
	Korean	917-920 MHz			
	China	840-844 MHz			
	China	920-924 MHz			
	Canada	902-927 MHz			
RFID MIN POWER	Set minimum working power range for RFID module:				
	0% <sup>Ⓓ</sup>	30%	60%	90%	
	10%	40%	70%	100%	
	20%	50%	80%		
RFID MAX POWER	Set maximum working power range for RFID module:				
	0%	30%	60%	90%	
	10%	40%	70%	100% <sup>Ⓓ</sup>	
	20%	50%	80%		
RFID INVENTORY MULTI	When disabled, printer will VOID tag if two or more tags are found before encoding.				
RFID REWRITE TAG	When disabled, printer will VOID tag if tag found is already encoded according to IATA RP1740c.				
RFID USER BANK SIZE	Setting of the RFID chip size:				
	TID <sup>Ⓓ</sup>	=	use value reported in TID area of RFID chip		
	Autocheck	=	verify the size of RFID chip user when loading paper (ignore value reported by TID).		
MODE	See IATA ITPS specifications.				
VERIFY	See IATA ITPS specifications.				



<b>DATE ANSWER</b>	See IATA ITPS specifications.
<b>LICENSE PLATE ANSWER</b>	See IATA ITPS specifications.
<b>AFI</b>	See IATA ITPS specifications.
<b>ENCODE RETRY</b>	See IATA ITPS specifications.
<b>VOID RETRY</b>	See IATA ITPS specifications.
<b>USER DATA AREA</b>	Encode fixed value in RFID chip user area. Values in Ascii Hex (e.g.AA30FF3C7F...).



## 6.9 Hexadecimal dump

This function is used for the diagnosis of the characters received from the communications port. Characters are printed as hexadecimal code and the corresponding ASCII code (see below). Each line is preceded by a counter in hexadecimal that indicates the number of bytes received.

During the startup, if you hold down the LF key, the device enters the self-test routine and print the setup report. The device remains in standby until a key is pressed or characters are received through the communication port (Hexadecimal Dump mode). For each character sent, the ticket shows the hexadecimal value and the ASCII codes (if the characters are underlined, the receive buffer is full). Shown below is an example of a Hexadecimal Dump:

HEXADECIMAL DUMP											
31	32	33	34	35	...	12345	...				
39	30	31	32	33	...	90123	...				
37	38	39	75	69	...	789ui	...				
68	6B	6A	73	64	...	hkjsd	...				
73	64	66	6B	6A	...	sdfkj	...				
66	73	64	66	6B	...	fsdfk	...				
65	69	6F	79	75	...	eioyu	...				
6F	72	69	75	77	...	oriuw	...				
6F	75	77	65	72	...	ouwer	...				
77	65	72	69	6F	...	werio	...				
72	69	6F	75	77	...	riouw	...				
6B	6C	73	64	66	...	kl sdf	...				
64	66	6B	73	64	...	dfksd	...				
73	64	66	6B	6A	...	sdfkj	...				
66	6B	F2	6A	73	...	fk≥j	...				
6A	6B	6C	68			jklh					

## 6.10 Calendar clock

### KPM302III, KPM302III TF

The device is equipped with a Real Time Clock. During power-up, held down the LF key to enter in the device configuration mode. Press the S1 key to enter in the clock configuration (see following figure). Press the LF key to modify date/time; the device will print the updated date and time.

Follow the instructions printed on the paper for the key functionality. The highlighted digit (the number is written in negative mode) indicates the digit to be modified. Press the LF key to modify the value of the highlighted digit; every single LF key pressure increases of 1 his value. Once the value 9 is reached the counting starts again from 0.

Press the FF key to move the cursor on the next digit; if the cursor position is on the latest digit you can proceed to next parameter by pressing the FF again.

Press the S2 key to exit and terminate the setting procedure.

### CLOCK SETUP

**[LF]** to modify date/time

**[FF]** to next field

**[S2]** to exit

<b>0</b> 1/01/21	12:00:00
0 <b>1</b> /01/21	12:00:00
01/ <b>0</b> 1/21	12:00:00
01/0 <b>1</b> /21	12:00:00
01/01/ <b>2</b> 1	12:00:00
01/01/2 <b>1</b>	12:00:00
01/01/21	<b>1</b> 2:00:00
01/01/21	1 <b>2</b> :00:00
01/01/21	12: <b>0</b> 0:00
01/01/21	12:0 <b>0</b> :00
01/01/21	12:00: <b>0</b> 0
01/01/21	12:00:0 <b>0</b>

Date Time Setting :


01/01/21 12:00:00

# TK202III PLAS, TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK

The device is equipped with a Real Time Clock. Proceed as follows to perform the clock configuration.

1


LF = ENTER SETUP...  
FF = EXIT SETUP...



During power-up, press the LF key to enter the setup configuration.

2


Set-Up type...  
Printer Set/Up



Press the LF key to select the Real Time Clock settings.

3

Set-Up type...  
Real Time Clock




Press the FF key to confirm the selection.  
The date/time values will be displayed.  
Follow the instructions printed on the paper.

4

0→1→2→3→4→5→6→7→8→9

Clock Setup  
01/01/21 12:00:00




The digit to be modified is highlighted.  
Press the LF key to modify the value;  
every press on the button increases the value by one.  
Once the max selectable value is reached the  
counting starts again from 0.

5

0→1→2→3→4→5→6→7→8→9

Clock Setup  
01/01/21 12:00:00



Use the FF key to move the cursor  
on the next digit; if the cursor position is  
on the latest digit, press the FF key  
to exit and save the date/time entered.  
Then the device is ready.




# **TK202III MET, TK302III MET EJ, TK302III MET TF-EJ**

The device is equipped with a Real Time Clock. Proceed as follows to perform the clock configuration.

**1**


LF = ENTER SETUP...  
FF = EXIT SETUP...



During power-up, press the LF key to enter the setup configuration.

**2**


Set-Up type...  
Printer Set/Up



Press the LF key to select the Real Time Clock settings.

**3**

Set-Up type...  
Real Time Clock




Press the FF key to confirm the selection.  
The date/time values will be displayed.  
Follow the instructions printed on the paper.

**4**

0 1 2 3 4 5 6 7 8 9

Clock Setup  
01/01/21 12:00:00




The digit to be modified is highlighted.  
Press the LF key to modify the value;  
every press on the button increases the value by one.  
Once the max selectable value is reached the  
counting starts again from 0.

**5**

0 1 2 3 4 5 6 7 8 9

Clock Setup  
01/01/21 12:00:00



Use the FF key to move the cursor  
on the next digit; if the cursor position is  
on the latest digit, press the FF key  
to exit and save the date/time entered.  
Then the device is ready.



## 7 ALIGNMENT

The device is provided with sensors for the use of alignment black mark in order to handle:

- roll of tickets with pre-printed fields and a fixed length;
- fan-fold module of tickets with pre-printed fields and a fixed length.

The alignment black mark may be formed by

- a black mark printed on the paper;
- a hole between two tickets;
- a gap between two labels.

All alignment sensors are “reflection” sensors: this kind of sensor emits a band of light and detects the quantity of light reflected to it. The presence of the black mark is therefore detected by the amount of light that returns to the sensor, considering that the light is reflected by the white paper and absorbed by the black mark.


To use tickets with holes or labels with gap, it is possible to use the same sensors as “transparence” sensors, coupled two by two: a beam of light is emitted by the transmitter sensor and the quantity of light which reaches the opposite receiver sensor is detected. The presence of a hole or a gap is detected evaluating the amount of light that arrives to the opposite sensor, considering that the paper doesn't allow the beam of light to reach the receiver, whereas a gap or a hole lets the light to reach the receiver.

The following paragraphs show how to correctly set the configuration parameters of device in order to assure the alignment.

## 7.1 Enable alignment

The device is provided with the two following sensors for alignment (see figure):

- SENSOR 1, a mobile sensor placed on the lower flat,
- SENSOR 2, a mobile sensor placed on the upper flat.



To guarantee the alignment, it is necessary to correctly choose the sensor to use for the black mark detection depending on the type of black mark and its location on the ticket.

To do this, you must enable the parameter “Black mark position” during the setup procedure (see [chapter 6](#)) and set the correct value of this parameter as described in the following table.

SENSOR USED	VALUE OF THE “BLACK MARK POSITION” PARAMETER	USING MODE OF SENSORS	BLACK MARK TYPE
-	Disabled	-	Alignment disabled
1	Bottom	Reflection	Black mark printed on the non-thermal side of paper
2	Top	Reflection	Black mark printed on the thermal side of paper
1 + 2	Transparent	Transparence	Hole between tickets or gap between labels

## 7.2 Calibration

The sensor calibration occurs automatically and consists in adjusting the quantity of light emitted to match the degree of whiteness of the paper used and the degree of black of the mark printed on paper.

The device automatically performs the self-calibration during the setup procedure only if the “Black mark position” parameter is set to a value other than “Disabled” (see [chapter 6](#)). Otherwise, the self-calibration can be started manually by pressing the S1 key during power-up.


When self-calibration starts, the device performs some paper feeds and then it prints the calibration result and the value of the PWM duty-cycle of the alignment sensor driver so that it can be perform an optimal black mark detection:

```
Autosetting black mark : OK
PWM Duty Cycle : 85.3%
```


The “Autosetting black mark” parameter indicates the result of the self-calibration procedure; OK will appear if it has been successful, NOT OK will appear if the procedure has failed.

After the printing of the procedure result, the device offers the execution of the function of paper characterization “Characterize Paper” and the change of the “Black mark threshold” parameter which represents the detection threshold of the black mark. Choosing the “Yes” value for the “Characterize Paper” parameter, the device prints a graphic representation (see following figures) of the outgoing voltage of the alignment sensor (expressed as a percentage) and the “Black mark threshold” value. This graphic representation is useful to set the most suitable value to assign to the “Black mark threshold” parameter and then to better identify the optimal threshold value which takes into account the variations of the signal and the small oscillations around zero.

The following figure shows an example of paper with the non-thermal paper printed with black marks: the outgoing voltage is constant while passing the white paper between two black marks and presents a peak at each black mark. In this case, the optimal value for the “Black mark threshold” parameter is placed about half of the peak.




The following figure shows an example of paper with holes: the outgoing voltage is constant while passing the paper between two holes and presents a variation at each hole. In this case, the optimal value for the “Black mark threshold” parameter is placed about half of the variation.



The following figure shows an example of paper with the non-thermal paper printed with black marks and other graphics: the outgoing voltage is constant while passing the white paper between two black marks, presents a peak at each black mark and presents some “noise” at each graphic.

In this case, the optimal value for the “Notch/B.Mark Threshold” parameter is located about halfway between the peak value and the maximum value of the “noise” (as shown in figure):




If the maximum value of “noise” read by the sensor is very close to the peak value, it might be difficult to place the value of the “Notch/B.Mark Threshold” at an intermediate point. In these cases, it is mandatory that the portion of paper between the point of printing end and the front notch is completely white (no graphics). In this way, the only next graphic detected by the sensor for alignment after the printing end will be the notch.

## 7.3 Alignment parameters


The “alignment point” is defined as the position inside the ticket to use for the black mark alignment. The distance between the black mark edge and the alignment point is defined as “black mark distance”.

The value of “black mark distance” varies from a minimum value of -5 mm to a maximum value of 66 mm.

If the setup parameter "Alignment type" is set on "Autocentering" value, the alignment point is automatically set at the center of the black mark (see following figure) and the parameter "Black mark distance" is ignored.




If the setup parameter "Alignment type" is set on "Edge" value and the parameter "Black mark distance" is set to 0, the alignment point is set at the beginning of the black mark (see following figure).







The following figure shows an example of paper with alignment point set by a positive value of “Black mark distance” (“Black mark distance” = + A).



The following figure shows an example of paper with alignment point set by a negative value of “Black mark distance” (“Black mark distance” = - A).



The following figure shows a simplified section of the device with the paper path and the distances (in millimetres) between the alignment sensors, the print head and the cutter (cutting line).



To define the alignment point you need to set the setup parameters that compose the numerical value of the parameter “Black mark distance” (see [chapter 6](#)).

For example, to set a notch distance of 15 mm, the parameters must be set on the following values:

Black mark distance sign	: +
Black mark distance [mm x 10]	: 1
Black mark distance [mm x 1]	: 5
Black mark distance [mm x .1]	: 0

The “Black mark distance” parameter, may be modified as follows:



- during the setup procedure of the device (see [chapter 6](#));
- by commands;
- by software (see [paragraph 6.2](#)).

# 8 MAINTENANCE

## 8.1 Printer paper jam


In the following sequence of images, the procedure for solving the paper jam inside the printer is described. For some models, only the internal printer group is represented.

**KPM302III, KPM302III TF**






4




Close the front cover of the device.

5



Close the upper covers of the device (see previous paragraphs).


6



Insert the paper (see previous paragraphs).

## TK302III PLAS. TK302III PLAS TF


1



Open the upper covers of the device  
(see previous paragraphs).


2

**TK302III PLAS**





Open the plastic  
front cover.

3



Open the front cover  
of the device.


4



Remove the damaged paper and check the presence  
for paper scraps inside the device. Carefully remove all  
paper scraps. If necessary use tweezers.




5



Close the front cover  
of the device.


6

**TK302III PLAS**




Close the plastic  
front cover.

7




Close the upper covers of the device  
(see previous paragraphs).

8





Insert the paper  
(see previous paragraphs).

1




Open the upper covers of the device  
(see previous paragraphs).

2




Remove the damaged paper and check the presence  
for paper scraps inside the device. Carefully remove all  
paper scraps. If necessary use tweezers.

3




Close the upper covers of the device  
(see previous paragraphs).

4




Insert the paper  
(see previous paragraphs).

1




Unscrew and remove the two front feet of the device.

2




Remove the vertical stacker.

3




Open the two upper covers of the device.

4




Open the two front covers of the device.




**5**


Remove the damaged paper and check the presence for paper scraps inside the device. Carefully remove all paper scraps. If necessary use tweezers.

**6**

Close the two front covers of the device.


**7**

Close the two upper covers of the device.

**8**


Insert the paper (see previous paragraphs).

9




Place the vertical stacker in the position shown in figure.

10




Fix the vertical stacker to the device by screwing the two feet previously removed.

1




Open the  
upper metal cover.

2




Open the  
front metal cover.

3





Open the upper cover  
of the device.

4




Open the front covers  
of the device.

5




Remove the damaged paper and check the presence for paper scraps inside the device. Carefully remove all paper scraps. If necessary use tweezers.

6




Close the two front covers of the device.

7



Close the two upper covers of the device.

8



Insert the paper (see previous paragraphs).


## 8.2 Triple feeder paper jam

**KPM302III TF, TK302III PLAS TF, TK302III MET TF-EJ**

In case of paper jam inside the triple feeder, the green led that corresponds to the input paper jammed flashes quickly. In this case, contact the customer service.

For ease of reference, in some figure is represented only the internal printer without the external chassis.

1



The green LED for the feeder jammed flashes quickly.

2

WWW.**CUSTOM4U**.it

Contact the customer service  
(see [chapter 11](#)).



## 8.3 Planning of cleaning operations

The regular cleaning of the device keeps the print quality and extends its life.  
The following table shows the recommended planning for the cleaning operations. If you use the device in dusty environments, you must reduce the intervals between cleaning operations.

For specific procedures, see [paragraph 8.4](#). For ease of reference, for some models is represented only the printer group without external chassis or triple feeder.


EVERY PAPER CHANGE	
Printhead	Use isopropyl alcohol
Platen roller	
Use isopropyl alcohol	
EVERY 5 PAPER CHANGES	
Autocutter (only if present)	Use compressed air
Paper path	
Use compressed air or tweezers	
Sensors	
Use compressed air	
Triple feeder (only if present)	Use the dedicated cleaning kit. Contact the customer service (see <a href="#">chapter 11</a> ).
EVERY 6 MONTHS OR AS NEEDED	
Display (only if present)	Use compressed air or a soft cloth Don't use any ammonia-based product.
Case	
Use compressed air or a soft cloth	

## 8.4 Cleaning

For periodic cleaning of the device, see the instructions below (for some models is represented only the printer group without external chassis or triple feeder.)


### Case

1




Disconnect the power supply cable.

2



#### ATTENTION:


Do not use alcohol, solvents, or hard brushes.  
Do not let water or other liquids get inside the device.



To clean the device,  
use compressed air or a soft cloth.


### Display

1



Disconnect the power supply cable.

2



#### ATTENTION:


Do not use alcohol, solvents, or hard brushes.  
Do not let water or other liquids get inside the machine.  
Do not use ammonia-based products.



To clean the display,  
use compressed air or a soft cloth.


## Printhead

1



Disconnect the power supply cable and open the device covers (see previous paragraphs).

2



### ATTENTION:


Do not use solvents, or hard brushes.  
Do not let water or other liquids get inside the machine.



Clean the printhead by using a non-abrasive cloth moistened with isopropyl alcohol.


## Platen roller

1



Disconnect the power supply cable and open the device covers (see previous paragraphs).

2



### ATTENTION:

Do not use solvents, or hard brushes.  
Do not let water or other liquids get inside the machine.  
To remove paper scraps, use tweezers or compressed air.




Clean the platen roller by using a non-abrasive cloth moistened with isopropyl alcohol.




## Sensors

1




Disconnect the power supply cable and open the device covers (see previous paragraphs).

2



### ATTENTION:


Do not use alcohol, solvents, or hard brushes.  
Do not let water or other liquids get inside the machine.  
To remove paper scraps, use tweezers or compressed air.



Clean the device sensors  
by using compressed air.


## Paper path

1




Disconnect the power supply cable and open the device covers (see previous paragraphs).

2



### ATTENTION:


Do not use alcohol, solvents, or hard brushes.  
Do not let water or other liquids get inside the machine.  
To remove paper scraps, use tweezers or compressed air.



Clean the area involved in the passage of paper  
by using compressed air.

## Triple feeder

1




Disconnect the power supply cable and open the device covers (see previous paragraphs).

2

www.CUSTOM4U.it


Contact the customer service (see [chapter 11](#)) to request the kit for the triple feeder.

3




Insert the edge with the rounded corners of the ticket of the cleaning kit in each of the three feeders until it comes out from the triple feeder a few of centimeters.

4



### ATTENTION:


Do not use alcohol, solvents, or hard brushes.  
Do not let water or other liquids get inside the machine.  
To remove paper scraps, use tweezers or compressed air.



Pull out the ticket of the cleaning kit by sliding it into the triple feeder.


## Autocutter

1




Disconnect the power supply cable and open the device covers (see previous paragraphs).

2



### ATTENTION:

Do not use alcohol, solvents, or hard brushes.  
Do not let water or other liquids get inside the machine.  
To remove paper scraps, use tweezers or compressed air.



Clean the autocutter  
by using compressed air.

## 8.5 Upgrade firmware


Firmware upgrade can be performed by using the “PrinterSet” software tool available on [www.custom4u.it](http://www.custom4u.it). To upgrade firmware, proceed as follows.

1




Login to the website [www.custom4u.it](http://www.custom4u.it), type in the product code of the device and download the latest firmware release available.

2




Connect the device to a PC directly (see [paragraph 4.6](#)), without using HUB devices.

3




Start the “PrinterSet” software tool.

4



Click on LOAD > FROM DEVICE and select the device connected to the PC.

5



Click on UPGRADE and follow the instructions shown on the screen.

**ATTENTION:** During saving, it is strongly advised against disconnecting the communication cable or to remove the power supply of PC or device.



# 9 SPECIFICATION

## 9.1 Hardware specification

GENERAL	
Sensors	Ticket presence, head temperature, ticket presence on output, mobile detectors of black mark or translucent gap/hole (setting by software), cutter position, front and upper cover open, external low paper
MTBF <sup>(1)</sup>	84080 hours
Emulations	SERVICE, ATB, BTP
INTERFACES	
USB port	480 Mbit/s
RS232 serial port	from 1200 bps to 115200 bps
ETHERNET port (only for models with Ethernet port)	10 Mbit/s, 100 Mbit/s
MEMORIES	
Receive buffer	64 Kbytes
Flash memory	16 Mbytes
RAM memory	512 Kbytes internal + 16 Mbytes external
Memory card SD (only for models with slot for SD card)	Capacity = max 2 Gbytes
PRINTER	
Resolution	203 dpi (8 dot/mm)
Printing method	Thermal, fixed head
Head life <sup>(2)</sup>	
Abrasion resistance <sup>(3)</sup>	100 Km (with recommended paper, 12.5% duty cycle)
Pulse durability	100 M (referred to each dot)



Printable barcode

UPCA, UPCE, EAN13, EAN8, CODE39, ITF,  
CODABAR, CODE93, CODE128, CODE32,  
PDF417, DATAMATRIX, AZTEC, QRCODE

Printing speed <sup>(2) (4)</sup>

High quality = 110 mm/s  
Normal = 170 mm/s  
High speed = 200 mm/s

## PAPER

Type of paper

Thermal rolls, heat-sensitive side on outside of roll  
Thermal fan-fold module

Paper width

54 mm (according to IATA BTP specifications - resolution 740)  
82.5 mm (according to IATA ATB specifications - resolution 722e)

Paper weight

according to IATA specifications

Paper thickness

according to IATA specifications

External roll diameter <sup>(5)</sup>

max. 300 mm

Internal roll core diameter

25 mm (+ 1 mm)

Core thickness

2 mm (+1 mm)

Core type

Cardboard or plastic

Paper end

Not attached to roll core

## AUTOCUTTER (only for models with autocutter)

Paper cut

Total cut

Estimated life <sup>(2)</sup>

1500000 cuts (with paper thickness 280 µm, ambient temperature)

## TRANSPONDER SPECIFICATIONS (only for models with RFID reader/writer)

Supported transponders

UHF ultra high frequency RFID  
(for models with UHF reader/writer)

UHF EPC Gen2



## DEVICES ELECTRICAL SPECIFICATIONS

Power supply	24 Vdc $\pm 10\%$
Medium consumption <sup>(6)</sup>	4.10 A
Typical consumption <sup>(4)</sup>	
KPM302III TK202III PLAS TK302III PLAS TK302III PLAS EJ-vSTK TK202III MET TK302III MET EJ	0.8 A
KPM302III TF TK302III PLAS TF TK302III MET TF-EJ	1 A
Standby consumption	0.14 A

POWER SUPPLY ELECTRICAL SPECIFICATIONS code 963GE020000112  
(OPTIONAL for KPM302III, KPM302III TF  
INCLUDED with TK202III PLAS, TK302III PLAS,  
TK302III PLAS TF, TK302III PLAS EJ-vSTK)

Power supply voltage	Auto Range, 90-132 VAC & 190-264 VAC
Frequency	from 47 Hz to 63 Hz
Output	24V, 4.17 A
Power	100 W

POWER SUPPLY ELECTRICAL SPECIFICATIONS code 963GE020000106  
(INCLUDED with TK202III MET, TK302III MET EJ, TK302III MET TF-EJ)

Power supply voltage	Auto Range, 90-132 VAC & 190-264 VAC
Frequency	from 47 Hz to 63 Hz
Output	24V, 4.17 A
Power	100 W



## ENVIRONMENTAL CONDITIONS

### Operating temperature

KPM302III KPM302III TF	from 0°C to +50°C <sup>(7)</sup>
---------------------------	----------------------------------

TK202III PLAS TK302III PLAS TK302III PLAS TF TK302III PLAS EJ-vSTK TK202III MET TK302III MET EJ TK302III MET TF-EJ	from 0°C to +40°C
--	-------------------

### Relative humidity (RH)

KPM302III KPM302III TF	from 10% to 80% (w/o condensation)
---------------------------	------------------------------------

TK202III PLAS TK302III PLAS TK302III PLAS TF TK302III PLAS EJ-vSTK TK202III MET TK302III MET EJ TK302III MET TF-EJ	from 10% to 85% (w/o condensation)
--	------------------------------------

Storage temperature	from -20 °C to +70 °C
---------------------	-----------------------

Storage relative humidity (RH)	from 10% to 90% (w/o condensation)
--------------------------------	------------------------------------

#### NOTES:

- (1) : Control board.
- (2) : Respecting the regular schedule of cleaning for the device components.
- (3) : Damages caused by scratches, ESD and electromigration are excluded.
- (4) : Referred to a standard CUSTOM receipt (L=10 cm, Density = 12.5% dots on).
- (5) : For external rolls diameter higher to Ø100 mm it's recommended to use a paper pretensioning device.
- (6) : Referred to the UL measurements (Speed/Quality = Normal, ticket length = 203 mm, 50% dots on, loop = 10 s).
- (7) : If you use the device with the power supply code 963GE020000112 or code 963GE020000106, supplied with device or as accessory, the operating temperature range is from 0 °C to +40 °C.





## 9.2 Device dimensions





All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed.

**KPM302III, KPM302III TF**

Length		
KPM302III		191 mm
KPM302III TF		307.5 mm
Height		
		123 mm
Width		
KPM302III		160 mm
KPM302III TF		168 mm
Weight		
KPM302III		3500 g
KPM302III TF		5200 g







**KPM302III (standard configuration)**









### **KPM302III (Cut&Drop configuration)**




# KPM302III (Burster configuration)






## KPM302III TF (standard configuration)






# KPM302III TF (Cut&Drop configuration)



# **KPM302III TF (Burster configuration)**





**TK202III PLAS, TK302III PLAS**  
**TK302III PLAS TF, TK302III PLAS EJ-vSTK**

---

Length

---

TK202III PLAS	252.1 mm
TK302III PLAS	

---

TK302III PLAS TF	331 mm
------------------	--------

---

TK302III PLAS EJ-vSTK	362.9 mm
-----------------------	----------

---

Height

---

TK202III PLAS	192.6 mm
TK302III PLAS	
TK302III PLAS TF	

---

TK302III PLAS EJ-vSTK	218.5 mm
-----------------------	----------

---

---

Width	216 mm
-------	--------

---

Weight

---

TK202III PLAS	4000 g
TK302III PLAS	

---


TK302III PLAS TF	4950 g
------------------	--------

---

TK302III PLAS EJ-vSTK	4270 g
-----------------------	--------


---










# **TK302III PLAS TF**





# **TK302III PLAS EJ-vSTK**








**TK202III MET, TK302III MET EJ, TK302III MET TF-EJ**

Length	
TK202III MET	306 mm
TK302III MET EJ	321 mm
TK302III MET TF-EJ	367.2 mm
Height	
134.5 mm	
Width	
178 mm	
Weight	
TK202III MET TK302III MET EJ	6500 g
TK302III MET TF-EJ	8200 g




**TK202III MET**








**TK302III MET EJ**





## TK302III MET TF-EJ




## 9.3 Device dimensions with ejector device code 976AV2110000001 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed.

### **KPM302III**

Length	212.7 mm
Height	123 mm
Width	160 mm
Weight	3500 g






## 9.4 Device dimensions with paper roll holder code 974BA010000001 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed and with Ø178 mm paper roll.

### TK202III PLAS, TK302III PLAS, TK302III PLAS EJ-vSTK

Length	463.1 mm
Height	195.4 mm
Width	216 mm




NOTES: When the paper roll holder is mounted on TK302III PLAS EJ-vSTK, it is necessary to properly levelling the rear feet of the device.

## 9.5 Device dimensions with height reduction kit code 976BB010000014 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed and with Ø178 mm paper roll.

### models with paper roll holder (code 974BA010000001 - optional)

Length	463.1 mm
Height	185.9 mm
Width	216 mm




## 9.6 Device dimensions with power supply container code 974BB010000001 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed and with Ø178 mm paper roll.

### models with paper roll holder (code 974BA010000001 - optional)

Length	463.1 mm
Height	195.4 mm
Width	216 mm




## 9.7 Device dimensions with metallic ticket tray code 976BB010000003 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed

### TK302III PLAS, TK302III PLAS TF

Length	464 mm
Height	189 mm
Width	216 mm




## 9.8 Device dimensions with plastic ticket tray code 976BD010000001 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed

### TK302III PLAS, TK302III PLAS TF

Length	464 mm
Height	192.6 mm
Width	216 mm




## 9.9 Device dimensions with ticket tray code 976BB010000004 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed

### TK202III PLAS, TK302III PLAS, TK302III PLAS EJ-vSTK

Length	456 mm
Height	190.6 mm
Width	216 mm




## 9.10 Device dimensions with metallic ticket tray code 974BB060000003 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed.

### TK302III MET EJ

Length	391.2 mm
Height	214.7 mm
Width	184.1 mm




## 9.11 Device dimensions with connectors protection code 974BB06000009 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed.

### TK202III MET, TK302III MET EJ

Length	342 mm
Height	134.5 mm
Width	179.5 mm









### **TK302III MET TF-EJ**

Length	367.2 mm
--------	----------

Height	134.5 mm
--------	----------

Width	179.5 mm
-------	----------




## 9.12 Device dimensions with ticket tray code 974BB060000005 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed.

### TK202III MET, TK302III MET EJ

Length	509 mm
Height	134.5 mm
Width	184.1 mm




## 9.13 Device dimensions with power supply container code 974BB010000006 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed.

### models with ticket tray (code 974BA010000005 - optional)

Length	635.1 mm
Height	134.5 mm
Width	184.1 mm



## 9.14 Device dimensions with paper roll holder code 974BB060000010 (optional)


All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed and with Ø178 mm paper roll.

### TK202III MET, TK302III MET EJ

Length	509 mm
--------	--------

Height	199.8 mm
--------	----------

Width	184.1 mm
-------	----------






## 9.15 Device dimensions with power supply container code 974BB010000004 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed and with Ø178 mm paper roll.

### models with paper roll holder (code 974BA010000010 - optional)

Length	534.5 mm
Height	199.8 mm
Width	185.7 mm




## 9.16 Device dimensions with front handle code 974BB060000008 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed.

### TK202III MET

Length	306 mm
Height	134.5 mm
Width	181 mm







### **TK302III MET EJ**

Length	321 mm
--------	--------

Height	134.5 mm
--------	----------


Width	181 mm
-------	--------





### TK302III MET TF-EJ

Length	367.2 mm
Height	134.5 mm
Width	181 mm






## 9.17 Device dimensions with fixing plate code 974BB060000007 (optional)

All the dimensions shown in the following figure are in millimetres and referred to devices with covers closed.


### TK202III MET

Length	306 mm
Height	137.5 mm
Width	184 mm



### TK302III MET EJ


Length	321 mm
Height	137.5 mm
Width	184 mm





**TK302III MET TF-EJ**

Length	367.2 mm
Height	134.5 mm
Width	178 mm





## 9.18 Dimensions of power supply and power cord


The following table shows the dimensions of power supply unit and power cords available for the device.

POWER SUPPLY ELECTRICAL SPECIFICATIONS code 963GE020000112 (OPTIONAL for KPM302III, KPM302III TF INCLUDED with TK202III PLAS, TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK)	
Length	146.2 mm
Height	39 mm
Width	75.2 mm
POWER SUPPLY ELECTRICAL SPECIFICATIONS code 963GE020000116 INCLUDED with TK202III MET, TK302III MET EJ, TK302III MET TF-EJ)	
Length	146.2 mm
Height	39 mm
Width	75.2 mm
POWER CORD WITH SHUKO PLUG code 26100000000311 (optional for every model)	
Length	2000 mm
POWER CORD WITH UK PLUG code 26100000000313 (optional for every model)	
Length	2000 mm


All the dimensions shown in following figures are in millimetres.



### **POWER SUPPLY code 963GE020000112**




### **POWER SUPPLY code 963GE020000106**






**POWER CORD code 26100000000311**



**POWER CORD code 26100000000313**






# 10 ACCESSORIES

The following table shows the list of available accessories for device.

---

**918BB030200000**

KIT UHF RFID  
(for technical specifications, see [paragraph 9.1](#))





---

**KPM302III TF, TK302III MET TF-EJ, TK302III PLAS TF**

**26300000000453**

WIRINGS KIT WITH LOW PAPER SENSORS  
length = 2 m  
(see [paragraph 10.2](#))




## **KPM302III, KPM302III TF**

---

**963GE020000112**

POWER SUPPLY


(for technical specifications, see [paragraph 9.1](#))



**26100000000311**

MAINS CABLE SHUKO PLUG


length = 2 m



**26100000000313**

MAINS CABLE UK PLUG

length = 2 m




**974AU010000305**

PAPER ROLL HOLDER


with cable length = 0.33 m

(see [paragraph 10.1](#))



**976AV210000001**

EJECTOR DEVICE








## **TK202III PLAS, TK302III PLAS, TK302III PLAS TF, TK302III PLAS EJ-vSTK**


**265000000000357**

USB CABLE  
with 90 degree connector  
length = 1.8 m




**265000000000048**

USB CABLE  
with 90 degree connector  
length = 3 m




**265000000000331**

SERIAL CABLE  
with 90 degree connector  
length = 1.8 m




**265000000000043**

SERIAL CABLE  
with 90 degree connector  
length = 3 m




**261000000000311**

MAINS CABLE SHUKO PLUG  
length = 2 m



**261000000000313**

MAINS CABLE UK PLUG  
length = 2 m






**TK202III PLAS, TK302III PLAS, TK302III PLAS EJ-vSTK**

---


**976BB010000004**

TICKET TRAY




**974BA010000001**

PAPER ROLL HOLDER




**976BB010000014**

KIT FOR HEIGHT REDUCTION  
(only for models with paper roll holder  
code 974BA010000001)



**976BB010000001**

KIT FOR POWER SUPPLY CONTAINER  
(only for models with paper roll holder  
code 974BA010000001)




**TK302III PLAS. TK302III PLAS TF**

---


**976BB010000003**

METAL TICKET TRAY




**976BD010000001**

PLASTIC TICKET TRAY



**976BA010000323**

KIT FOR BURSTER CONFIGURATION






**TK202III MET, TK302III MET EJ, TK302III MET TF-EJ**

---


**974BB060000008**

FRONT HANDLE



**974BB060000009**

CONNECTORS PROTECTION



**974BB060000007**

FIXING PLATE




**TK302III MET EJ**

---


**974BB060000003**

METAL TICKET TRAY




**974BB060000010**

PAPER ROLL HOLDER




**974BB060000004**

KIT FOR POWER SUPPLY CONTAINER  
(only for models with paper roll holder  
code 974BB060000002)




**974BB060000005**

TICKET TRAY



**974BB060000006**


KIT FOR POWER SUPPLY CONTAINER  
(only for models with ATB ticket tray  
code 974BB060000002)



## 10.1 Paper roll holder code 974AU010000305 (optional)

For the device is available an external paper roll holder kit, supplied as accessory. The kit makes it possible to use paper rolls with larger diameter (up to 150 mm).

The following figure shows the dimensions for holder support and paper roll pin (all the dimensions in figure are in millimetres).




### NOTE:

For external rolls diameter higher to 100 mm it's recommended to use a paper pre-tensioning device.

## 10.2 Wirings kit with low paper sensor boards code 26300000000453 (optional)


For the device is available a kit of wirings with low paper sensor, supplied as accessory. The kit makes it possible the connection between triple feeder and low paper sensors.

The kit includes three wirings assembled with three low paper sensors boards, as shown in following figure.




For the assembly procedure, proceed as follows:

1



Remove the cover for the triple feeder connectors by levering with a small slotted head screwdriver.

2



Connect the three wirings to the connectors of triple feeder.







# 11 TECHNICAL SERVICE

In case of failure, contact the technical service accessing the website [www.custom4u.it](http://www.custom4u.it) and using the support tools on the homepage. It is advisable to keep the identification data of the product at hand.

The product code, the serial number, the hardware release number and the firmware type can be found on the two product labels (see [paragraph 3.5](#)).

The firmware release number (SCODE) can be found:

- on the setup report (see [paragraph 6.1](#)),
- connecting the device to a PC and starting the “PrinterSet” tool (see [paragraph 6.2](#)).







**CUSTOM S.p.A.**

World Headquarters

**Via Berettine, 2/B - 43010 Fontevivo, Parma ITALY**

**Tel. +39 0521 680111 - Fax +39 0521 610701**

**info@custom.biz - www.custom.biz**

*All rights reserved*

[www.custom.biz](http://www.custom.biz)